

SPIRENT AVALANCHE

APPLICATION LOAD TESTING SOLUTION

AVALANCHE 3100B

Spirent's Avalanche™ appliance solution provides capacity, security and performance testing for network infrastructures, Web application infrastructures and Triple Play services ensuring Quality of Service (QoS) and Quality of Experience (QoE) for your customers.

APPLICATIONS

- Network Performance Testing
- Web Application Testing
- Triple Play Testing
- Security Testing

In today's digital world, it's essential that the performance of content aware networks, security systems and Web applications are carefully tested to ensure that business transactions and communication are not impacted. The Spirent Avalanche 3100B is a line rate, 1 Gbps and multi-10Gbps Layer 4-7 stateful traffic performance solution that is capable of high throughput security testing of over 8 Gbps of bulk encrypted traffic. Avalanche 3100B users now have the ability to test devices to their limits at line rate simulating daily traffic and understand the impact under worse case scenarios.



PERFORMANCE AND FLEXIBILITY

In addition to 1 Gbps and 10Gbps of Layer 4-7 stateful traffic and 25 million connections (Avalanche 3100B GT supports over 60,000,000 connections), testers are able to specify load variables such as user sessions, new user sessions per second, transactions, transactions per second, connections or connections per second. One load profile can be specified for an entire test, or a separate load profile can be defined for each group of simulated users. You can also turn on and off any protocol at any phase during the test. This flexible approach enables different actions, network characteristics and loads to be specified for each group of simulated users. In addition, up to eight simultaneous users can utilize the resources of a single Avalanche 3100B appliance to maximize your investment and test efficiencies.

AVALANCHE 3100 APPLIANCE PERFORMANCE EXAMPLES*

	Avalanche 3100B	Avalanche 3100B GT
HTTP GETs/Sec	900,000	900,000
HTTPS GETs/Sec	300,000	300,000
HTTP Bandwidth	40 Gbps/70 Gbps	40 Gbps/70 Gbps
HTTps Bandwidth	8 Gbps	8 Gbps
Sustained Connections	30,000,000	60,000,000
Sustained IPSec Tunnels	200,000	400,000
Sustained Video Sessions	200,000	200,000

*The above numbers are obtained using two 3100B appliances, one being used as client and other one as server. Unidirectional/Bidirectional Traffic

USER REALISM

Avalanche supports the configuration of extremely realistic user behaviors so tests accurately reflect your company's network usage patterns. The system interacts seamlessly with sites using dynamic and interactive content, HTML links and fill-in online forms. Multiple types of browsers can be emulated, providing detailed control over browser connection behavior, SSL versions, authentication and browser client headers. User behavior such as think times and "clickaways" (HTTP aborts) can be simulated, and the system also supports HTTP basic and proxy authentication.

Avalanche sends realistic requests that include dynamically filled-in fields from a list of provided values, or values captured from a previous response such as order numbers, session IDs or transaction IDs. Avalanche also supports high-performance testing of Web services to ensure mission-critical services will perform under heavy loads. The system can also verify received content by searching for one or more strings in a response.

Avalanche quickly identifies potential points of failure by stress-testing the infrastructure. With tremendous performance at your disposal, highly realistic simulated user and network traffic can be generated, recreating a wide range of real-world loading scenarios. This proactive approach enables you to correct trouble spots and bottlenecks before network slowdowns or costly outages occur. Ideal for equipment manufacturers, service providers and enterprise network operators, Avalanche eliminates the need to build expensive and cumbersome test infrastructures. The challenge of analyzing performance and security in today's Triple Play voice, video and data networks requires the best testing equipment you can get. By accurately emulating user and network behavior, the Avalanche load testing appliances help ensure tight security and optimum application performance.

FEATURES & BENEFITS

- **40Gbps Line Rate Stateful Traffic**—Provides the capability to generate line rate stateful traffic up to 10Gbps allowing trunk ports to be directly tested or determine the impact of multiple GigE ports being aggregated over 20Gbps—in addition the Avalanche 3100 is capable of bidirectional testing and can operate in excess of 70Gbps from a single 3100 appliance
- **Flexible Load Profile**—Flexible load profile offers testers the flexibility to specify load variables such as connections per second, concurrent connections, transactions per second, new user sessions per second and concurrent users
- **Expandable**—The Avalanche 3100 is designed for the future in mind with the ability to be expanded to up to 4-ports of 10Gbps interfaces for a total of 40Gbps of unidirectional line-rate application traffic
- **Real-Time Statistics**—Real-time statistics across all protocols and reporting tool that makes analyzing results faster and easier
- **Network Devices Performance Testing**—Provides performance and capacity testing on a variety of network devices including: Firewall, Application Firewall, Load Balancer, Cache, Proxy, URL Filter, Content Filter, Anti-Virus, Anti-Spyware, Reverse-Proxy, SSL Accelerator, HTTP/HTTPS Accelerator, WAN Accelerators, SMTP Relay, IDS/IPS, IPSec VPN Gateway and SSL VPN Gateway
- **Application Server Performance Testing**—Validates the performance of several types of real servers including Web Server, CIFS Server, Application Server, Mail Server, DHCP Services, FTP Server, DNS Server, Telnet Server, RTSP/RTP QuickTime Streaming Server, Multicast Server, RTMP Servers, NFS, and more
- **Triple Play Performance Testing**—Performs Triple Play testing, validates Triple Play service from the user's point of view with realistic voice calling, unicast and multicast streaming video, and simulates Internet data traffic using static IP address or IP address assign by DHCP over PPPoE, VLAN and Stacked VLANs (e.g. Q-in-Q)
- **Web Application Testing**—Performs Web application testing including Web services, SOA, ERP and CRM applications with Spirent Avalanche's application testing capability to support cookie, session ID, dynamic link, automatic follow redirect, additional header, content validation, SOAP message, think time, variable think time and variable assignment
- **Network Security Testing**—Provides extensive testing for secure network communication, vulnerability assessment with over 3000 attack profiles and user authentication including: IPSec, SSL, 802.1x, Network Access Control (NAC) and RADIUS

TECHNICAL SPECIFICATIONS

SPIRENT AVALANCHE 3100 APPLIANCE	
Feature	
Number of Test Users	12 Test Users
Type of Simulation	Client and Server
Network Interfaces	<ul style="list-style-type: none"> • 12x 10/100/1000 Copper • 12x 10/100/1000 Fiber • 12x 10/100/1000 Copper and 4x 10/100/1000 Fiber • 4x 10Gbps Fiber Interface (SFP +Transceiver Included)
Network Access Protocol	DHCP, PPPoE and IPSec
Network Realism	Line speed limitation, network latency, packet loss and fragmentation
IP Version Supported	IPv4 and IPv6
Encapsulation Protocol	802.1Q and 802.1 Q-in-Q
Transport	TCP, UDP, SSLv2, SSLv3 and TLSv1
Data Protocol	HTTP, HTTPS, FTP (Active/Passive), DNS, TELNET, SMTP, POP3, IMAP4, CIFS, RADIUS, MM4, RTMP, ICMP, NFS and Capture/Replay
Authentication	802.1x, Network Access Control (NAC), Radius
Extended Protocols	BitTorrent, Gnutella, MSN, Yahoo, SKYPE, SQL, MYSQL, Oracle, SMB, NFS, Remote Desktop, Exchange, LDAP
Voice Protocol	SIP over TCP and SIP over UDP
Voice Codec Supported	G711A, G711U, G.723.1, G726-32, G.728 and G729AB
Voice Quality Measurement	MOS R-factor
Video Protocol	Flash Streaming using RTMP/RTMPT, Unicast Streaming Quicktime RTSP/RTP, Unicast Streaming RealNetwork RTSP/RTP, Unicast Streaming Microsoft MMS, Multicast Streaming IGMPv2, IGMPv3 and MLDv2
Video Codec Supported	MPEG-1, H.261, MPEG-2. H.262, MPEG-4. H.264
Video Quality Measurement	MDI measurements along with additional stats to detect picture quality
Vulnerability Assessment	L2/L4 DDOS Attacks and 3500+ L4/L7 Application Attacks including SANs Top-20 Internet Security Attacks
Reporting	Integrated CSV test results analyzer fully customizable with report generation in PDF and HTML
Automation	GUI to TCL and Automatic goal seeking using WorkSuite Manager
SPIRENT AVALANCHE 3100 APPLIANCE	
Dimensions	5.25" H x 16.53" W x 19.75" D Fits standard 19" rack, 3U high
Weight	31 lbs. (14 kg)
Operating Environment	5°C–35°C
Non-Operating Environment	0°C–50°C
Relative Humidity	10%–90% (non-condensing)
Power Requirements	115-230V, 50/60 Hz – 460W
Regulatory Approvals	FCC Class A, EN 55022 Class A, EN 55024

SPIRENT AVALANCHE 3100B

AVALANCHE 3100B APPLICATION LOAD TESTING SOLUTION

REQUIREMENTS

An IBM® compatible PC must meet the following minimum requirements to run the Spirent Avalanche:

- One 10/100/1000Base-T unshielded twisted pair (UTP) cable
- One 10 Mbps or 10/100/1000 Mbps Ethernet NIC card
- Intel® E6300 Core 2 Duo 4 (or equivalent)
- One serial port
- Minimum of 2 GB of RAM
- Minimum 10 GB free space on the hard drive
- Windows® XP operating system, Service Pack 2 (SP2)
- An SVGA color monitor (or equivalent) and a mouse
- Microsoft Terminal Services™ or HyperTerminal™, or equivalent communications software package
- DVD-ROM drive

ORDERING INFORMATION

- Avalanche 3100B with 12-Port GIGE Copper NICs: **CEE-HWB-036**
- Avalanche 3100B with 12-Port GIGE Fiber NICs: **CEE-HWB-035**
- Avalanche 3100B with 12-Port GIGE Fiber and 4-Port 10G NICs: **CEE-HWB-031**
- Avalanche 3100B with 12-Port GIGE Copper and 4-PORT 10G NICs: **CEE-HWB-030**
- Other configurations are available

SPIRENT SERVICES

Professional Services

- Test lab optimization: Test automation engineering services
- Service deployment and service-level optimization: Vendor acceptance testing, SLA benchmarking, infrastructure and security validation
- Device scalability optimization: POC high scalability validation testing

Education Services

- Web-based training: 24 x 7 hardware and software training
- Instructor-led training: Hands-on methodology and product training
- Certifications: SCPA and SCPE certifications

Implementation Services

- Optimized new customer productivity with up to three days of on-site assistance

SPIRENT GLOBAL SERVICES

Spirent Global Services provides a variety of professional services, support services and education services – all focused on helping customers meet their complex testing and service assurance requirements. For more information, visit Global Services at www.spirentcom.com/gs or contact your Spirent sales representative.

AMERICAS 1-800-SPIRENT • +1-818-676-2683 • sales@spirent.com

EUROPE AND THE MIDDLE EAST +44 (0) 1293 767979 • emeainfo@spirent.com

ASIA AND THE PACIFIC +86-10-8518-2539 • salesasia@spirent.com