PROFISHARK 100M

ALL-IN-ONE FAST ETHERNET TROUBLESHOOTER

The Ultimate Solution for 100M Field Testing & Monitoring

The ProfiShark 100M is designed for traffic capture on both regular Ethernet and Real-Time Industrial Ethernet, making it the perfect troubleshooting tool for field engineers as well as for long-term traffic collection. Easy to use and pocket-sized, ProfiShark 100M provides flexibility without compromising performance, as it manages to capture 100% of full-duplex 100M traffic passing through.

Combine the ProfiShark 100M with a Windows, Linux or macOS computer through its USB 3.0 port (USB 2.0 compatible) for a complete network analysis solution. The ProfiShark 100M captures packets of all sizes and types and offers a wide assortment of capture and configuration options, information, and statistics, through the ProfiShark Manager.



○ 10/100M monitoring on USB

USB powered

Non-intrusive, passive monitoring

Hardware aggregation

In-Line mode

8 ns hardware timestamp

802.3af and VoIP compliant, PoE passthrough

Customizable real time statistics

In-depth network port diagnostics

Low level error and bandwidth monitoring

Live capture

Direct capture to disk

Invisible to the network

LONG-TERM TRAFFIC CAPTURE

The long-term capture feature is designed to help you catch intermittent problems in the act. By connecting a NAS to the ProfiShark, captures can be done for long periods of time. Included in ProfiShark software package.

Full-duplex 100M wirespeed capture
Ringbuffer or normal capture mode

Split capture to different files, based on time or size

Compatible with all Intel-based Synology NAS systems

TECHNICAL SPECIFICATIONS

CONNECTORS	ACCESSORIES
2 x RJ45 8 pins 1 x USB 3.0 1 x 5 VDC optional input	1.8 m USB 3.0 cable RJ45 cable Pouch USB key
DIMENSIONS (WXDXH)	NETWORK LATENCY
69 x 124 x 24 mm 2.72 x 4.88 x 0.94 in	0
WEIGHT	SYSTEM REQUIREMENTS
170 g — 0.37 lb	Dual Core Processor — 4 GB memory — USB 3.0 port
COMPLIANCE	LEDS
RoHS — CE	2 x Speed/Status — 2 x Link/Activity — 1 x Power
SUPPORTED OS	
Windows 7 / 8 / 10 (32/64-bit) / 11 — Linux — macOS	

ORDER REFERENCE





C1AP-100