

EasyView™ Light Meter with Memory

Large LCD display with advanced illuminance functions and features

Features:

- Wide measurement range to 99,990Fc (999,900Lux) with resolution of 0.001Fc and 0.01Lux
- Luminous intensity (candela) calculations
- Store and recall up to 50 measurements, includes relative or real time clock stamp
- Ripple function excludes the effect of stray light from the primary light source measurement
- Auto Power off with disable feature
- Multiple point average function
- Timed-Hold, Relative in absolute value or % deviation, and Comparator function with high low alarms
- Cosine and color corrected, CNS 5119 Class II
- Complete with built-in stand, light sensor and protective cover with 36" (0.9m) cable, protective holster, 6 AAA batteries, and carrying case



CE

Specifications	
Display Counts:	999,999 count LCD
Fc Range:	9.999Fc, 99.99Fc, 999.9Fc, 9,999Fc, 99,990Fc
Lux Range:	99.99Lux, 999.9Lux, 9999Lux, 99,990Lux, 999,900Lux
Max. Resolution:	0.001Fc/0.01Lux
Basic Accuracy:	±3%
Cosine & Color Corrected:	Yes
Dimensions:	5.9x2.8x1.4" (150x72x33mm)
Weight:	11.29oz (320g)

Ordering Information:

EA33EasyView™ Light Meter with Memory

EXTECH INSTRUMENTS CORPORATION
285 Bear Hill Road, Waltham, MA 02451-1064, U.S.A.
Phone: 781-890-7440 • FAX 781-890-7864

ISO 9001:2000 CERTIFIED

"Make mine an Extech!"™
www.extech.com



07/06 - R2