



NetDisturb

Impairment Emulator Software for IP Networks (IPv4 & IPv6)




Common Key Features for the Standard and Enhanced Editions

- Simultaneous support of **IPv4** and **IPv6**
- Client-Server architecture based on the SOAP mechanism which uses the HTTP protocol and the XML format for the exchanges between the Client and the Server
- **NetDisturb** is an Ethernet bridge to avoid any network configuration
- use of standard Ethernet Network Interface Cards up to 1 Gbps
- Symmetric or Asymmetric **bandwidth limitation** with router simulation
- Very easy to use and intuitive Graphical User Interface
- 16 configurable flows per direction
- **Aggregates** of flows can be defined (set of flows sharing the same Delay & Jitter characteristics)
- **User-defined rules for disturbances**: pattern trigger, starting time after delay or number of packets received, stop impairments after number of received packets or elapsed time, loops and more...
- Predefined filter parameters based on the main protocol header fields (MAC, MPLS, VLAN, IP, TCP and UDP headers) and user-defined pattern filter
- **Unidirectional** or **bi-directional** packet impairments
- **Impairments**: Latency, Loss, Duplication, bandwidth limitation, Delay and Jitter, Content impairment (mathematical laws or user-defined files)
- Change the impairment law **on-the-fly** for a flow
- Ability to impair the remaining network traffic that could be either only the IP packets or all the Ethernet frames
- Connections per flow: impairments are applied to the flow or to each connection of the flow
- Ethernet / Internet modes (Out-of-Sequence packets)
- **Command Line Interface (CLI)** to use **NetDisturb** in test beds
- Ethernet Jumbo frames supported (payload up to 17,976 bytes)
- Statistics display and export detailed statistics into a file
- **Accuracy = 1 millisecond resolution**



TR instruments
Tel.: +420 541 633 670
Fax: +420 541 212 413
Křižíkova 70, 612 00 Brno
tri@trinstruments.cz



Comparison between NetDisturb Standard Edition and NetDisturb Enhanced Edition

Features

Impairment of IPv4 & IPv6 packets, ARPs and Ethernet frames

Filter parameters to define a flow:

* Activity rules:

- Start/Stop after a time limit or a packet counter or a pattern trigger
- Loop to reapply the rule with delay between each iteration

* Packet filters: source address, destination address, source port, destination port, protocol, DSCP DiffServ (ToS), MPLS, VLAN, MAC address...

* User-defined pattern filter based on Ethernet packet content

16 User-defined flows to impair using filters and other flows to impair without using filters

Dynamically modify impairments on-the-fly per flow in each direction when running

Aggregates of flows (set of flows sharing the same delay and jitter characteristics)

View Per-Flow statistics and NICs statistics

Accuracy = 1 millisecond

Standard impairments: drop/loss, duplicate, delay (latency), jitter, bandwidth limitation, congestion, packet error, bit error, reorder, burst errors

Delay from 1 millisecond up to 10 seconds in each direction

Emulate bandwidth up to 1 Gbps

Impairments by using the IP protocol field

Definition of flows to disturb based on protocol primitives:

- **ARP** (ARP Operation Code)
- **DHCP** (DHCP Message Type)
- **DNS** (DNS Message Type, DNS Message Operation)
- **FTP** (FTP Command, FTP Returned Status)
- **FTP-DATA**
- **HTTP** (HTTP Method, HTTP Returned Status)
- **NTP**
- **RTP** (Audio Payload Type, Video Payload Type, DTMF)
- **SIP** (SIP Method, SIP From, SIP To, SIP Returned Status)
- Detailed log events per flow



Yes



Yes

Yes

Yes

Yes

Yes

Yes

Yes

Yes

Yes

Yes

Yes

Yes

Yes

Yes

Yes

Yes

Yes

No

Yes

No

Yes

No

Yes

No

Yes

No

Yes

No

Yes

No

Yes

No

Yes

No

Yes

No

Yes